

156mm x 100mm

SOUNDFREAQ®

Welcome to Soundfreaq.

We are a co-op of craftsmen— designers and engineers— with a passion for great sound. We develop our products from the ground up to offer premium sound quality and wireless versatility.

Thank you for choosing Pocket Kick. We sincerely hope that you enjoy your new speaker. Please share your experience with us:

connect@soundfreaq.com

Happy Listening to you.

We invite you to join our Soundfreaq community:

FACEBOOK

TWITTER

facebook.com/soundfreaq

twitter.com/soundfreaq

soundfreaq.com

SOUNDFREAQ® Playback via Bluetooth




1. Slide up the **Power switch** to turn on Pocket Kick.
2. Press the **Pair** button on Pocket Kick to enter pairing mode – the Pair indicator light will flash rapidly.
3. Open the Bluetooth settings on your Bluetooth-enabled device. Once Pocket Kick is recognized “**Pocket Kick**” will appear in the list of Bluetooth devices. Select “**Pocket Kick**” to pair with your device. The Pair indicator light will turn solid once Pocket Kick is successfully connected.
4. You can use the **Play controls** on Pocket Kick to control playback.

Notes:

- On most devices, no password is needed to pair, however, if a password is requested the default password is “1234”.
- You can change the volume by either using the volume buttons on Pocket Kick or changing the volume on your paired device. For max volume, turn both volumes to maximum.

Charging the Built-in Battery



Pocket Kick has a built in rechargeable battery. To charge, plug into a powered USB port such as a computer, phone or tablet charger. It is suggested to use the micro USB cable included in the package for charging your device. The battery indicator combined with **Power switch** will indicate the charging status.

Mode	Charging	Fully Charged
Standby	Blinking Green (Slowly)	Blinking White (Slowly)
Power on (not connected)	Blinks Green	Blinks White
Bluetooth or Aux in mode	Solid Green	Solid White

Note: For charging or charging while playing Pocket Kick, please use minimum 1A USB power adaptor. Please fully charge Pocket Kick before using.

Playback via AUX IN

Connect any device with a headphone jack by plugging the 3.5mm cable (included) into the **AUX IN** jack. When the **AUX IN** jack is inserted, the system will only play via **AUX IN**.

Note: In order to save the energy, please unplug the line in cable from the Aux Line In of Pocket Kick when do not use.



Pocket Kick

Using Hands-free Calling



1. Slide up the **Power switch** to turn on Pocket Kick.
2. Establish the Bluetooth connection between the system and your mobile phone.

To answer a call

When a call arrives, the music playback is muted and a ring tone is heard from the system. Press **Call** button and speak using the microphone.

To end a call

To end a call, press **Call** button. If you were listening to music when the call arrived, it will be resumed when the call has finished.

Notes:

- If a call arrives, press and hold **Call** button for about 2 seconds to reject it.
- If no call arrives, press and hold **Call** button for about 2 seconds to redial the phone number that is dialed last time.

For further assistance with setting up Pocket Kick, we are available at:

support@soundfreaq.com
soundfreaq.com/support